


CASE Remote Plus manual

1 Power Switch and Reset



Here are 3 switch status:

ON: Remote control status. The device can be connected to camera.

BATTERY: mobile power supply status. The device can output 5V/1A from USB to charge other devices.

OFF: shutdown status.

2 Indicator Lights

SYS Light

Flickering: starting or updating


Stable: ready for use



Power Light

Four green indicator lights: the more lights on, the higher battery level.

3 External Interfaces



WLAN Network socket: Software update and function extension

USB socket: Connect with camera

Charging port: charging for the CASE+

4 Packing

CASE Remote Plus *1

CASE+ Pouch *1

White power cord *1

CASE+ manual *1

5 How to Use



Step 1: APP Installation

IOS User:

Please download CASE Remote app in APP Store.

Android User:

Please download CASE Remote app in Google Play or our official web: www.caseremote.com.

App Update:

App will be update continuously, please pay attention to our official website news, and update your app timely, following the update instruction.

Important: For the first use of APP, you have to input SSID for a verification. The SSID, which starts with "CASE_R", is at the back of device. Please make sure your mobile device is connected to the Internet by 2G/3G/4G or Wi-Fi.

Step 2: Connect to your camera

Connect CASE+ to your camera with a USB cable. Then, turn on CASE+ and camera power on.

Note: A factory USB cable along with your camera is recommended for the connection. This package does NOT include this USB cable.



Step 3: Connect to the Wi-Fi hotspot


Connect the Wi-Fi hotspot in your setting. The password can be found at the back of CASE+.

SSID	CASE_R0d2
PWD	cf9ad742
S/N	TR119BB6A00C

Step 4: Start the APP

Please refer to the iPhone 2.0 APP manual for the software operation.

You can download the manual from our website.



Website: www.caseremote.com

Email: support@caseremote.com

